Crow Wireless Device	Product Codes	Product Description	SPC Gen1 FW 3.16 TWW Legacy Transceiver [v4.7]	SPC Gen1 FW 3.16 TWW New Transceiver [v0.1.0.29]	SPCevo FW 4.1.2 TWW Old Transceiver [v4.7]	SPCevo FW 4.1.2 TWW New Transceiver [v0.1.0.29]	AIC-1200 FW 1.0.5 TWW New Transceiver [v0.1.0.29]
Old PIR	V54538-F109-A100	WPIR Wireless 12m PIR detector PET	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old curtain PIR	V54538-F110-A100	WPIR-CRT Wireless curtain PIR detector	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old stylish MAG	V54538-F111-A100	WMAG Wireless Magnetic Contact Slim	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old MAG with external contact	V54538-F114-A100	WMAG-I Wrls. Magnetic Contact w. input	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old smoke detector	V54538-F113-A100	WSMK Wireless smoke alarm	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old shock	V54538-F141-A100	WMAG-S Wireless Mag Cont & shock	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old glassbreak	V54538-F117-A100	WGB Wireless Glass Break Detector	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old flood sensor	V54538-F118-A100	WFLOOD Wireless Flood Detector	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old internal siren	V54538-F115-A100	WSIR-INT Wireless internal siren	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old external PIR	V54538-F124-A100	WPIR-EXT AM Wrls. Ext PIR c/w pet	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old external siren	V54538-F116-A100 V54538-F116-A200 V54538-F116-A300	WSIR-EXT-B Wireless external bell blue WSIR-EXT-R Wireless external bell red WSIR-EXT-O Wireless ext. bell orange	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old remote WRMT [*2]	V54538-F117-A100	WRMT Remote control w. 4 button	Fully supported	Not supported	Fully supported	Not supported	Not supported
Old Panic button WPAN [*3]	V54538-F118-A100	WPAN Wireless personal alarm button	Fully supported	Not supported	Fully supported	Not supported	Not supported
Old keypad	V54543-F154-A100	WKP-SIM keypad with fobs	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Old wall plug repeater	V54552-F107-A100	WRPTR Wireless Signal Repeater Plug	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Updated TWW Devices							
WPIR-CAM Wrls. PIRCAM internal	V54552-F110-A100	WPIRCAM-INT Wrls. PIRCAM internal	Not supported	Not supported	Not supported	Fully supported	Fully supported
WPIR-CAM Wrls. PIRCAM external	V54552-F111-A100	WPIRCAM-EXT Wrls. PIRCAM external (Gray)	Not supported	Not supported	Not supported	Fully supported	Fully supported
New PIR programmed as CT2025	V54538-F109-A200	WPIR Wrls. 12m PIR with PI	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New CRT PIR programmed as CT2025	V54538-F110-A200	WPIR-CRT Wireless curtain PIR detector	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New MAG with ext contact (WMAG-I)	V54538-F114-A300	WMAG-I Wrls. Magnetic Contact w. input	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New Smoke & Heat detector	V54538-F112-A100	WSMK Wrls. smoke alarm round	Not supported	Fully supported	Not supported	Fully supported	Fully supported
New shock (WMAG-S)	V54538-F141-A200	WMAG-S Wrls. Mag cont & shock	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New flood sensor	V54538-F118-A200	WFLOOD with water sensitive cable	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New internal siren	V54538-F115-A200	WSIR-INT Wireless internal siren	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New external siren	V54538-F147-A100	WSIR-EXT Wireless External Siren	Not supported	Fully supported	Not supported	Fully supported	Fully supported
New remote WRMT [*2*3]	V54543-F117-A300	WRMT Remote control w. 4 button	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
New panic button WPAN [*2*3]	V54543-F118-A300	WPAN Wireless Personal Alarm Button	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported
Cube Repeater [*1]	V54554-F108-A100	WRPTR Wrls. Simple CUBE Repeater	Fully supported	Fully supported	Fully supported	Fully supported	Fully supported (No tamper function)
New keypad	V54543-F154-A300	WKP-SIM keypad with fobs	Not supported	Not supported	Not supported	Fully supported	Fully supported
New external PIR	V54538-F124-A300	WPIR-EXT Wrls. Ext PIR AM c/w pet	Not supported	Not supported	Not supported	Fully supported	Fully supported

*1
Note: Cube repeater does not support supervision signals for synchronistic devices such as the internal and external PIRCAM, Keypad, new round WSMK and the new WSIR-EXT and WSIR-INT.
- PIRCAM, video transmission via the repeater is not supported.
- Ext and Int Sirens, Outputs (On and Off) transmission are not support via the repeater
- WSMK alarms are not transmitted via the repeater. (WSMK must have direct transmission to the Panel transceiver)

*2
Max 64 devices on Transceiver firmware v0.1.0.29 (AIC-1200, SPC Gen1 and SPCevo)

*3
Max 64 devices on Transceiver firmware 4.6.
Max 20 devices on Transceiver firmware 4.7.

Note: The old WRMT V54543-F117-A100 and the old WPAN V54543-F118-A100 are not compatible with the Transceiver v0.1.0.29. If you need to upgrade your transceiver to v0.1.0.29 to support other wireless devices, then you will need to replace the WRMT and WPAN with the new version devices V54543-F117-A300 and V54543-F118-A300

Note : There is a maximum of 16 synchronous devices that can be added to the V29 transceiver. This table includes the these products, the WSMK, WKP-SIM, WSIR-EXT and -INT and the WPIRCAM-EXT and -INT.
Note: The SPCEvo and AIC-1200 panels support a max of 8 PIRCAM's

Note:When reactivating devices after a Transceiver upgrade, Devices will not reactivate via a repeater. Devices that are not in range of the panels transceiver, will have to be brought in range of the transceiver to be reactivated and then reinstalled in the correct location.

	Going from transceiver v47 to v29 on the SPC Gen1	Reactivate Process	Going from transceiver v47 to v29 on the SPC Evo	Reactivate Process	
	Old PIR	Powercycle device by removing batteries for 10 sec	Old PIR	Powercycle device by removing batteries for 10 sec	
	Old curtain PIR	Powercycle device by removing batteries for 10 sec	Old curtain PIR	Powercycle device by removing batteries for 10 sec	
	Old stylish MAG	Powercycle device by removing batteries for 10 sec	Old stylish MAG	Powercycle device by removing batteries for 10 sec	
	Old MAG with external contact	Powercycle device by removing batteries for 10 sec	Old MAG with external contact	Powercycle device by removing batteries for 10 sec	
	Old smoke detector	Press and hold Pairing button for 3 sec and release	Old smoke detector	Press and hold Pairing button for 3 sec and release	
	Old shock	Powercycle device by removing batteries for 10 sec	Old shock	Powercycle device by removing batteries for 10 sec	
	Old glassbreak	Powercycle device by removing batteries for 10 sec	Old glassbreak	Powercycle device by removing batteries for 10 sec	
	Old flood sensor	Press and hold Pairing button for 3 sec and release	Old flood sensor	Press and hold Pairing button for 3 sec and release	
	Old internal siren	Powercycle device by removing batteries for 10 sec	Old internal siren	Powercycle device by removing batteries for 10 sec	
	Old external PIR	Powercycle device by removing batteries for 10 sec	Old external PIR	Powercycle device by removing batteries for 10 sec	
	Old external siren	Powercycle device by removing batteries for 30 seconds	Old external siren	Powercycle device by removing batteries for 30 seconds	
	Old remote WRMT [*2]	N/A	Old remote WRMT [*2]	N/A	
	Old Panic button WPAN [*3]	N/A	Old Panic button WPAN [*3]	N/A	
	Old keypad	Powercycle device by removing batteries for 10 sec	Old keypad	Powercycle device by removing batteries for 10 sec	
	Old wall plug repeater	Remove from AC and battery for 10 sec. Replace battery and AC	Old wall plug repeater	Remove from AC and battery for 10 sec. Replace battery and AC	
	WPIR-CAM Wrls. PIRCAM internal	N/A	WPIR-CAM Wrls. PIRCAM internal	N/A	
	WPIR-CAM Wrls. PIRCAM external	N/A	WPIR-CAM Wrls. PIRCAM external	N/A	
	New PIR programmed as CT2025	Powercycle device by removing batteries for 10 sec	New PIR programmed as CT2025	Powercycle device by removing batteries for 10 sec	
	New CRT PIR programmed as CT2025	Powercycle device by removing batteries for 10 sec	New CRT PIR programmed as CT2025	Powercycle device by removing batteries for 10 sec	
	New MAG with ext contact (WMAG-I)	Powercycle device by removing batteries for 10 sec	New MAG with ext contact (WMAG-I)	Powercycle device by removing batteries for 10 sec	
	New Smoke & Heat detector	N/A	New Smoke & Heat detector	N/A	
	New shock (WMAG-S)	Powercycle device by removing batteries for 10 sec	New shock (WMAG-S)	Powercycle device by removing batteries for 10 sec	
	New flood sensor	Press and hold Pairing button for 3 sec and release	New flood sensor	Press and hold Pairing button for 3 sec and release	
	New internal siren	Powercycle device by removing batteries for 10 sec	New internal siren	Powercycle device by removing batteries for 10 sec	
	New external siren	N/A	New external siren	N/A	
	New remote WRMT	Remove v47 from WRMT then press the 2 SOS buttons to reactivate	New remote WRMT	Remove v47 from WRMT then press the 2 SOS buttons to relearn	
	New keypad	N/A	New keypad	N/A	
	New panic button WPAN	Press and hold button for 5 sec and release to reactivate	New panic button WPAN	Press and hold button for 5 sec and release to reactivate	
	Cube Repeater	Remove charging cable.Open unit and press and hold button until all three led's turn red. Release button and wait for all LED's to turn off. Replace charging cable to reactivate.	Cube Repeater	Remove charging cable.Open unit and press and hold button until all three led's turn red. Release button and wait for all LED's to turn off. Replace charging cable to reactivate.	